peerless®

Installation and Assembly - Neck Security Fastener Pack for LG Display Models: 26LG30DC, 32LG30DC, 37LG30DC, 42LG30DC, 47LG50DC, 52LG50DC

Model: MIS571

IMPORTANT! Read instruction sheet before you start installation and assembly.
Before you start make sure all parts listed are included with your product.

This product is UL Listed. It must be installed by a qualified professional installer.

Parts List

	Description	Qty	Part #
A	M4 x 25 mm socket pin screw	4	520-2082
B	M4 flat washer	4	540-2081
C	# 8 split lock washer	4	540-2044
D	4 mm allen wrench	1	560-9646

A



B



C



D



Some parts may appear slightly different than illustrated.

⚠ WARNING

- Do not overtighten! Overtightening may cause permanent damage to the screen. Torque to 26-35 in • lb (30-40 kg • cm).

1 Slide screen onto screen base until screen mounting holes and screen base mounting holes align as shown in figure 1.1. Attach screen to Plasma stand using four M4 x 25 mm socket pin head screws (**A**) lock washers (**C**) and flat washers (**B**) as shown in figure 1.2. Tighten with 4 mm security allen wrench (**D**).

fig 1.1



fig 1.2



Visit the Peerless Web Site at www.peerlessmounts.com

For customer care call 1-800-729-0307 or 708-865-8870.

© 2008, Peerless Industries, Inc. All rights reserved.
All other brand and product names are trademarks or registered trademarks of their respective owners.